



\*本說明書所記載之所有內容與功能規格廠商有權更動且不另行通知。  
\*本說明書所記載之所有內容與功能規格將以實物為準。

### ●產品說明

- Lighter S是專門為手槍開發的一款體積小重量輕的發光器。
- 由於Lighter S的體積小,使用者可以輕鬆的改裝到BB槍護木或魚骨內部或置入市售的滅音管,讓使用者的BB槍或滅音管也具有發光器的功能。
- 隱蔽式電源指示燈設計,夜戰時電源指示燈的光線不容易被發現。
- Lighter S內部發光元件為高功率紫外線LED可以使綠色夜光彈激發出非常高的亮度,而對於紅光夜光彈所激發出的亮度效能較差。
- 內部為高壓電路,請勿自行拆解以免發生觸電。
- 自動關機說明:
  - 開機後40分鐘無任何射擊,即自動關機。
  - 電池低電量時,電源燈將以紅光閃爍數次後自動關機。
- LED電量顯示:(每秒閃爍一次)
  - 綠光:高電量
  - 橘光:中電量
  - 紅光:低電量,當低電量時,LED將快速閃爍數次後自動關機。
- 使用Lighter S時,當安裝於BB槍上,眼睛絕對不可直視槍口,以避免誤操作或BB槍故障誤擊而發生意外。
- 為延長內建鋰電池使用年限,每2個月至少充電一次。



\*All the specifications and contents in this manual are subject to change without notice.  
\*All the specifications and contents are only for reference, please make the object as the standard.

### ●Description


- The Lighter S, is a small and lightest tracer unit designed for the pistol.
- Because of its small dimension, it enables users easily to install it into their silencers or airsoft gun hand-guards as long as their inner space is larger than the dimension of Lighter S. (Diameter: 27mm or 1.06 inches, length: 67.3mm or 2.65inches)
- Lighter S could light up green tracer BBs with very high brightness but lighten red tracer BBs with medium brightness.
- Do not disassemble the Lighter S to prevent high voltage electrical shock.
- It automatically switches off under the following conditions:
  - Device has idled for 40 minutes
  - When the battery power is low, after the power indicator blinks in red color for 3 seconds.
- Remaining power indicator (flash once per second)
  - Green light: high power
  - Orange light: medium power
  - Red light: low power
- Do not look straight into the muzzle to check the installation of the device to prevent any accident like mistakenly pulling the trigger or firing the gun.
- In order to extend the built-in Li-Poly battery life as much as possible, please charge it least once every 2 months.

### ●產品使用與操作說明

- 第一次使用前必須先進行充電,將前蓋以逆時針方向旋開,將MicroUSB充電線分別插入Lighter S與USB充電器,此時充電指示燈將亮起表示充電中。



- 當充電指示燈滅,表示充電完成,移除充電線,將前蓋以順時針方向旋緊。
- 將Lighter S安裝於槍管前方鎖緊。
- 按下電源開關,電源指示燈將亮起(每秒閃爍一次)。



- 閒置40分鐘不使用則自動關機。
- 不使用時則按下電源開關關機,LED指示燈滅。
- 當電源指示燈顯示紅色快速閃爍數次後自動關機,就表示電池沒電,需要進行充電。

### ●規格

- ※ 支援綠色夜光彈。
- ※ 支援35PRS連發速。
- ※ 內建鋰電池,充電時間2.5小時。
- ※ 充電一次可供應22000發夜光彈射擊。
- ※ LED電源與電量顯示。
- ※ FCC, CE, ROHS
- ※ 尺寸:直徑27mm,總長度67mm
- ※ 重量32g(不含轉接頭)
- ※ 配件:
  - ▶ 說明書x1
  - ▶ MicroUSB充電線x1
  - ▶ M11正牙轉M14逆牙轉接頭x1.

### ●Instruction

- Should charge the Lighter S before using it the first time. Please refer to the following steps:

- Unscrew the front cap by turning counterclockwise to open the Lighter S.
- Insert one end of the MicroUSB charging cable into the Lighter S and the other end into the charger.



- The charger indicator would light on to indicate that the Lighter S is charging now.



- When the Lighter S is fully charged, the charging indicator would light off. Pull out the charging cable and then screw the front cap by turning clockwise to close the device.
- Install the Lighter S in front of the muzzle.
- Press the power button and then the power indicator will blink (once per second).
- The Lighter S would turn off automatically after leaving it idle for 40 minutes.
- When not in use, press the button power to turn off the Lighter S as well as the power indicator.
- The following situations indicate that the battery is dead and needs charging:
  - You could not turn on the Lighter S.
  - You could turn on the Lighter S but the power indicator is in red light, flashes quickly a few times and then it turns off.

### ●Specifications

- ※ Supports green tracer BBs.
- ※ Supports up to 35PRS.
- ※ Built-in li-Poly battery, Charging time: 2.5 Hours.
- ※ Accessories:
  - ▶ MicroUSB charging cable x 1,
  - ▶ Adaptor x 1 (M14 anti-clockwise thread to M11 clockwise thread)
- ※ Fully charged battery would last over 22000rounds.
- ※ Led power indicator / battery power indicator
- ※ FCC, CE, ROHS compliant
- ※ Dimension: Diameter: 27mm (1.06 inch), length: 67.3mm (2.65 inch)
- ※ Weight: 32g (without adaptor)