



QB78 Deluxe	Description
0100	Tube
0200	Inside Plug
0300	Locating Screw
0400	Valve Ass'y
0401	Piercing Body
0402	Filter
0403	Screen
0404	Washer
0405	Spacer
0406	Check Valve Spring
0407	Piercing Pin
0408	Valve Stem Ass'yTube
0409	O Ring, 19mm
0410	Exhaust Valve Body
0500	Valve Set Screw
0600	Hammer
0700	Hammer Spring
0800	Cocking Block
0900	Hammer Pin
1000	Cocking Pin
1100	Breech Bolt Ass'y177 cal
1101	O Ring
1200	Breech
1300	Bolt Knob
1400	Breech Bolt Set Screw
1500	Breech Gasket
1600	Lock Washer
1700	Hold Down Screw

QB78 Deluxe	Description
1800	Trigger Casing Ass'y
1900	Breech Plug
2000	Tube Plug
2100	Casing Lock Washer (2)
2200	Front Casing Screw
2300	Rear Casing Screw
2400	Strap Ass'y
2500	Barrel.177 cal
2700	Barrel O ring (3)
2800	Barrel Set Screw
2900	Hardwood Stock
3100	Plain Washer
3200	Locating Screw Nut
3300	Safety
3400	Tube Cap Ass'y
3401	O Ring, 19mm
3700	Sight Package

QB78 Deluxe

Description

1800	Trigger Casing Assembly
1801	Trigger Casing
1802	Trigger Casing Cap
1803	Screw (2)
1804	Trigger
1805	Sear Assembly
1806	Sear Spring
1807	Screw (2)
1808	Safety Rod
1809	Trigger Spring
1810	Screw
1811	Safety Spring
2400	Strap Assembly
2401	Strap
2402	Strap Screw
2403	Strap Screw Nut
3700	Sight Package
3701	Rear Sight
3702	Rear Sight Base
3703	Screw (3)
3704	Front Sight
3705	Elevation Adjusting Screw
3706	Pin
3707	Spring

