



# EASY LIPO CHARGER USER MANUAL



## Warning

Please correctly connect the Easy LiPo Charger to power and battery pack according to the procedure outlined in user manual.

Please use this charger under supervision.

Please place the charger in a dry environment and keep it away from fire.

Please don't tightly pull and drag the power cord or replace it, or else the fire/electric shock will be caused.


Please don't touch the charger and power with wet hands or it will bring in electric shock. To extend the working life of the charger, please remove it from power once charging is finished. Children must be watched by adults to use the charger.

04

## Product Introduction

Thank you for purchasing Specna Arms Easy LiPo Charger.

This charger is compact and light, which can charge 2s or 3s of battery pack, especially there is separated corresponding balance port for each battery pack. Before using it, please read the user manual carefully.



01

## Specification

Charge current:	800 mA/cell
Cut off:	V>4.2V/cell &  <0.05A/cell
Input Voltage:	110-240V AC 50/60Hz
Display:	3x Bicolor LED
Max. Charging Current:	3x 800 mA
Size:	100 mm* 60mm * 35mm
Weight:	105g
Model:	B3PRO Compact Charger


02

## Instructions

1. Please firstly connect the Easy LiPo Charger to power, while the three power LEDs will turn from red to green, which indicating that the charger works in good order.

2. Please connect the battery pack to 3s balance port, while the three power LEDs will all turn into red and charging begins. Please note once the charging of one cell is done, the corresponding power LED for it will turn green.

3. When the three power LEDs all turn green, the charging for 3S battery pack is finished.



03

